

Q: How much is the efficiency of parallel computing?
How to set the number of cores used for various parallel computing?

A: The efficiency of parallel computing depends on solver types.
Please refer to the data below for more information.
To access the benchmark information for each analysis, go to the Femtet help menu, *Home>Benchmark*, and click [Benchmark] for more information on efficiency.

To set the number of cores, go to
Application Menu>General Settings>Parallel Computing, and deselect [Automatic Setting] and specify [Maximum Number of Cores to Use].